
















HL
2.10d













HL
2.10d













HL
2.10c

















S10 S5;S12 56;61 48R



S10 68 S10



c









da 80













db 80 S14 S10 79












- Ⓓ **Torsionsfederwelle hintenliegend HL**
- ⒼⒷ **Rear-mounted torsion spring HL**
- Ⓕ **Arbre à torsion à l'arrière HL**
- ⒼⓁ **Torsieveeras aan de achterzijde HL**









- Ⓓ **B = Bodensektion**
- S = Schlossektion**
- M = Mittelsektion**
- K = Kopfsektion**





- ⒼⒷ **B = floor section**
- S = lock section**
- M = middle section**
- K = header section**

- Ⓕ **B = section basse**
- S = section de serrure**
- M = section centrale**
- K = section haute**


- ⒼⓁ **B = bodemsectie**
- S = slotsectie**
- M = middensectie**
- K = kopsectie**









- Ⓓ Schadenfall Federbruch
- ⒼⒷ Damage claim: spring fracture
- Ⓕ Dommage rupture de ressort
- ⒼⓁ Schade veerbreuk



a




b



ca




cb




cb-a



cc



d



e



- D** Einzelteilliste für Sectionaltore
mit Torsionsfederwelle
(vorneliegend - VL, hintenliegend - HL)
- GB** Part list for sectional doors
with torsion spring
(front-mounted - VL, rear-mounted - HL)
- F** Liste des pièces individuelles pour portes
sectionnelles avec arbre
de ressort à torsion
(à l'avant - VL, à l'arrière - HL)
- NL** Lijst met reserveonderdelen voor
sectiedeuren met torsieveeras
(aan de voorzijde - VL, aan de achterzijde - HL)

VL + HL

1L



42661 ...

1R



42661 ...

3



65318 ...

4L



30501315

4R



30501316

6



65390 ...

7



11400017

13



30475000

14R







42500 ...

14L







42500 ...



VL + HL

16L  11500007	16R  11500008	18  30592002
19  30592001	20L  30280000	20R  30281000
21L  30501019	21R  30501020	27  82570001
28  30085000	29  30059000	30  42000001
35R 	35L 	
37  65340000	38  65330000	39 Ti 25  11100029




VL + HL

44	 B	45L	 11100002		
45R	 11100003	47	 660080 ...	48R	 36004003
48L	 36004002	49	 36009001	56	 36010001
57R	 36002002	57L	 36002001	58	 11100030
59	 30462000	60	 30501204	61	 36006001
67	 S	68	 36004001		

VL + HL

69  64535 ...	70  30545002	71  30546002
72  30546011	73  30539001	74  30024007
75  11100021	76  64581000	77  30540000
78  64565000	79  30503010G	80  65977 ... 65978001 f. Kass.
86  M	87  K	
88  11400075	89  11400062	90  11400076

VL + HL

91  11400065	92  30107000	93R  30503012
93L  30503011	94  30503013	95  11100011
96  65170 ...	97  30501010	98L  30501011
98R  30501031	100  11400066	101R  30501200G
101L  30501199G	103  30501314	104  30501313
105R  11400069	105R  11400070	106  36103001